




TWR-K65F180M Quick Start Guide

Power-Efficient, 180 MHz ARM®
Cortex®-M4-based MCUs with FPU,
up to 2 MB Flash and 256 KB SRAM

Tower System
Development
Platform



Get to know the TWR-K65F180M




Figure 1: Front side of TWR-K65F180M




Figure 2: Back side of TWR-K65F180M

TWR-K65F180M

Freescale Tower System Development Platform

The TWR-K65F180M board is designed to work either in standalone mode or as part of the Freescale Tower System, a modular development board platform that enables rapid prototyping and tool re-use through reconfigurable hardware. Begin constructing your Tower System evaluation board platform today by visiting freescale.com/Tower for additional Tower System boards and compatible peripherals.



Step-by-Step Installation Instructions

In this Quick Start Guide, you will learn how to set up the TWR-K65F180M board and run the included demonstrated software. For more detailed information, review the user manual at freescale.com/TWR-K65F180M.

1 Configure the Hardware

Install the included battery into the VBAT (RTC) battery holder. Then, connect one end of the USB cable to the PC and the other end to the Power/OpenSDA micro-AB connector on the TWR-K65F180M module. Allow the PC to automatically configure the USB drivers if needed.

2 Run the Quick Start Demo

The LEDs on the board, D6 and D7, will gradually illuminate as the board is tilted. When rotated around the accelerometer's x-axis the orange LED (D7) will illuminate. Similarly, the yellow LED (D6) will gradually illuminate as rotated around the y-axis. The actual accelerometer data is printed to a terminal window via the UART module.

3 Download Software and Tools

Download installation software and documentation under **“Jump Start Your Design”** at freescale.com/TWR-K65F180M.



Expanded Software and Tools Now Available for Kinetis MCUs

Additional details regarding the Quick Start Demo are included as part of the Kinetis software development kit (SDK).

To take your design to the next level, leverage the Kinetis SDK and other online enablement software and tools for Kinetis MCUs, available for download at the relevant links listed here.

- Kinetis software development kit at [freescale.com/ksdk](https://www.freescale.com/ksdk)
- Kinetis Design Studio IDE at [freescale.com/kds](https://www.freescale.com/kds)
- Bootloader for Kinetis MCUs at [freescale.com/kboot](https://www.freescale.com/kboot)

1177-1005 F180M Jumper Options

The following is a list of all the jumper options. The default installed jumper settings are indicated in the shaded boxes.

Jumper	Option	Setting	Description
J1	MCU power connection	ON	Connect V_SUPPLY and V_BRD with MCU_PWR
		OFF	Disconnect V_SUPPLY and V_BRD with MCU_PWR
J2	VDD and VDDA connection	ON	Connect VDD and VDDA
		OFF	Disconnect VDD and VDDA
J3	VBAT power selection	1-2	Connect VBAT to on board 3.3V supply from V_SUPPLY
		2-3	Connect VBAT to the higher voltage between on board 3.3V supply or coin cell supply
J4	Tamper signal header	2-3	Tamper signal header
J6	RESET button connection	1-2	When powering the OPENSDA MCU, bootloader mode can be selected
		2-3	When OPENSDA MCU is not powered, RESET button can be used
J8	5V power connection	ON	Connect P5V_TRG_USB to input of on board 3.3V regulator
		OFF	Disconnect P5V_TRG_USB to on board 3.3V regulator

1.1.1.1.1.1 F180M Jumper Options (cont.)

Jumper	Option	Setting	Description
J9	Board power selection	1-2	V_SUPPLY comes from OPENSDA MCU (K20) USB regulator
		3-4	V_SUPPLY comes from on board 1.8V regulator
		5-6	V_SUPPLY comes from on board 3.3V regulator
		7-8	V_SUPPLY comes from K65 USB regulator
J10	TWRPI power selection	ON	Connect V_BRD to TWRPI connector power
		OFF	Disconnect V_BRD to TWRPI connector power
J13	USB power enable connection	ON	Connect PTD8 to USB power enable for MIC2005
		OFF	Disconnect PTD8 to USB power enable for MIC2005
J14	USB over-current flag connection	ON	Connect PTD9 to USB over-current flag for MIC2005
		OFF	Disconnect PTD9 to USB over-current flag for MIC2005

1. Jumper Options F180M Jumper Options (cont.)

Jumper	Option	Setting	Description
J16	USB ID connection	1-2	Connect PTD15 to USB ID pin on MicroUSB connector J15
		2-3	Connect PTE10 to USB ID pin on MicroUSB connector J15
J17	Pulldown connection on CD/DAT3 for MicroSD slot	ON	Disconnect pull down resistor on CD/DAT3 pin on MicroSD slot
		OFF	Connect pull down resistor on CD/DAT3 pin on MicroSD slot
J20	MCU reset connection on JTAG connector	ON	Connect MCU reset on pin10 of JTAG connector J18
		OFF	Disconnect MCU reset on pin10 of JTAG connector J18
J21	JTAG Power Connection	ON	Connect on-board 5V supply to JTAG port (supports powering board from external JTAG probe)
		OFF	Disconnect on-board 5V supply from JTAG port
J22	Accelerometer INT connection	1-2	Connects INT1 from MMA8451 to PTE27
		3-4	Connects INT2 from MMA8451 to PTE28

1777-1005 F180M Jumper Options (cont.)

Jumper	Option	Setting	Description
J23	K65 VREGIN selection	1-2	VREG_IN0 connected with ONBOARD_USB_VBUS
		1-3	VREG_IN1 connected with ONBOARD_USB_VBUS
		2-4	VREG_IN0 connected with ELEV_USB_VBUS
		3-4	VREG_IN1 connected with ELEV_USB_VBUS
J24	Potentiometer connection	ON	Connect potentiometer to ADC1_SE16
		OFF	Disconnect potentiometer to ADC1_SE16
J27	/RSTOUT connection	1-2	MCU reset signal connected to /RSTOUT (A63) on primary elevator
		2-3	PTD10 connected to /RSTOUT (A63) on primary elevator
J30	SDRAM power connection	ON	Connect V_BRD to SDRAM chip
		OFF	Disconnect V_BRD to SDRAM chip

1111-1000 F180M Jumper Options (cont.)

Jumper	Option	Setting	Description
J32	SWD clock disconnection	ON	Connect SWD_CLK from OPENSDA circuit to K65 MCU to allow debugging using OPENSDA
		OFF	Disconnect SWD_CLK from OPENSDA circuit to K65 MCU to allow J-Link or U-Link debug
J33	UART2 RX connection	1-2	Connect UART2_RX to elevator
		2-3	Connect UART2_RX to OPENSDA UART RX
J34	UART2 TX connection	1-2	Connect UART2_TX to elevator
		2-3	Connect UART2_TX to OPENSDA UART TX
J35	I2C connection with accelerometer	1-2	Connect I2C0_SCL with accelerometer SCL
		3-4	Connect I2C0_SDA with accelerometer SDA
J36	USB 5V power connection	1-2	Connect MiniUSB connector (J7) VBUS with U12 pin 1
		2-3	Connect P5V_ELEV with U12 pin 1



et Started



Download installation software and documentation under
“**Jump Start Your Design**” at freescale.com/TWR-K65F180M.

Visit freescale.com/TWR-K65F180M or
freescale.com/Kinetis for more information
on the TWR-K65F180M board.

Support

Visit freescale.com/support for a list of phone
numbers within your region.

Warranty

Visit freescale.com/warranty for complete
warranty information.

For more information, visit
freescale.com/TWR-K65F180M,
freescale.com/Kinetis or freescale.com/Tower

Freescale, the Freescale logo and Kinetis are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. ARM and Cortex are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. © 2015 Freescale Semiconductor, Inc.

